


## TCL Android TV Remote User Manual

Get to know the functions of the buttons on your TCL Android TV remote control.

**A - POWER** Turn TV on and off  
**B - SETTINGS** Display the TV Settings Menu  
**C - HOME** Return to Home screen  
**D - OPTIONS** Open the Options Menu  
**E - BACK** Return to previous screen  
**F - SOURCE** Open input source shortcut  
**G - GOOGLE ASSISTANT** Wake-up Google Assistant  
(Only available when connected to the Internet)  
**H - CHANNEL** To change channel up or down for Antenna Live TV  
**I - VOLUME** Raise or lower volume  
**J - VIRTUAL KEYBOARD** Open the onscreen virtual keyboard  
**K - NETFLIX** Open Netflix  
**L - YOUTUBE** Open YouTube



TIP: Follow the on-screen guide to pair the remote control with the TV when you press the Google Assistant button for the first time

Note: You can also install the Android TV Remote Control app on your Android or iOS mobile devices. [Click here to learn more.](#)